



Note:- Plumb wall first then fit sheet bracing to both sides

100 x 10 Dyna bolt or 10mm allthread chemset into slab 80mm penetration

Low Nib Wall Detail

SCALE NTS

| Detail | | | |
|---------------------|-----|-------------|------|
| Low Nib Wall Detail | | | |
| Drawn by | M.F | Date | 2013 |
| Checked | | Date | |

DIVERSEBUILDERS

P.O Box 196
 114 Melville Street
 Numurkah VIC 3636
 T 03 5862 2712
 F 03 5862 3583
 E info@diversebuilders.com.au
 W diversebuilders.com.au



WARNING:-

All information and designs contained within this document are copyright to Diverse Builders
 RBP Reg No. DBU-8259 - CBU-6016 & NSW 89500C